

Barkbusters® Application Chart

Updated: 15/06/2016



All recommended fitting options are for motorcycles with OEM specification. If fitting assistance is required, contact Barkbusters at info@barkbusters.net
 For new models and the most up-to-date applications, visit - www.barkbusters.net

APRILIA	BETA	BMW	BUJELL	CAN AM	DUCATI	GAS GAS
GILERA	HARLEY DAVIDSON	HONDA	HUSABERG	HUSQVARNA	HYOSUNG	KAWASAKI
KTM	KYMCO	MOTO GUZZI	OSET	PIAGGIO	SHERCO	SUZUKI
SWM	TM	TRIUMPH	URAL	VESPA	YAMAHA	

	JET	EGO	VPS	STORM	CARBON	BBZ
<i>GUARD Colours Available -</i>	BK (Black) BU (Blue) GR (Green) OR (Orange) RD (Red) WH (White) YE (Yellow)	BK (Black) BU (Blue) GR (Green) OR (Orange) RD (Red) WH (White) YE (Yellow)	BK (Black) BU (Blue) GR (Green) OR (Orange) PK (Pink) RD (Red) SL (Silver) WH (White) YE (Yellow)	BK (Black)	CF (Carbon Fibre)	BK (Black)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
-------	-----	-----	-----	-------	--------	-----

APRILIA

MANA 850	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
MANA 850GT						BBZ-001 (Fabric guards)
PEGASO 650	JET-001 (Complete kit) + B-054 (x 2 connector)		BHG-151 (Hardware) + B-054 (x 2 connector) + VPS-003 (VPS guards)	BHG-151 (Hardware) + B-054 (x2 connector) + STM-003 (Storm guards)	BHG-151 (Hardware) + B-054 (x 2 connector) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit JET-001 & BHG-151: 6mm Bolts required for bar end, or bar can be drilled/tapped to take 8mm bolt. For extra clearance, two clamp connectors (off set) are required. Code: B-054 (x2)</i>						
RSV TUONO 1000 Twin	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
RXV 450 2009 on	JET-001 (Complete kit) + BSS-00 (Adaptor kit)	EGO-001 (Complete kit) + BSS-00 (Adaptor kit)	BHG-151 (Hardware) + BSS-00 (Adaptor kit) + VPS-003 (VPS guards) <i>or</i> VPS-007 (MX complete kit)	BHG-151 (Hardware) + BSS-00 (Adaptor kit) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
<i>NOTE: To fit JET-001, EGO-001 & BHG-151: Due to handlebar size, an additional saddle set is required. Code: BSS-00</i>						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
RXV 550 2009 on	JET-001 (Complete kit) + BSS-00 (Adaptor kit)	EGO-001 (Complete kit) + BSS-00 (Adaptor kit)	BHG-151 (Hardware) + BSS-00 (Adaptor kit) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + BSS-00 (Adaptor kit) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
<i>NOTE: To fit JET-001, EGO-001 & BHG-151: Due to handlebar size, an additional saddle set is required. Code: BSS-00</i>						
SCAREBEO SCOOTER 125/200	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
SHIVER 2013	BHG-055 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-055 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-055 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-055 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-007-01-NP or STM-007-01-BK: Remove original handlebar end weight and use Fitting Option A from the instructions.</i>						
SXV 450 2009 on	JET-001 (Complete kit) + BSS-00 (Adaptor kit)	EGO-001 (Complete kit) + BSS-00 (Adaptor kit)	BHG-151 (Hardware) + BSS-00 (Adaptor kit) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + BSS-00 (Adaptor kit) + STM-003 (Storm guards)		
<i>NOTE: To fit JET-001, EGO-001 & BHG-151: Due to handlebar size, an additional saddle set is required. Code: BSS-00</i>						
SXV 550 2009 on	JET-001 (Complete kit) + BSS-00 (Adaptor kit)	EGO-001 (Complete kit) + BSS-00 (Adaptor kit)	BHG-151 (Hardware) + BSS-00 (Adaptor kit) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + BSS-00 (Adaptor kit) + STM-003 (Storm guards)		
<i>NOTE: To fit JET-001, EGO-001 & BHG-151: Due to handlebar size, an additional saddle set is required. Code: BSS-00</i>						
BETA						
RR 400 to 2012	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)	BHG-152 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
RR 498 2013 on	JET-001 (Complete kit) + BSS-02 (Adaptor kit)	EGO-001 (Complete kit) + BSS-02 (Adaptor kit)	BHG-151 (Hardware) + BSS-02 (Adaptor kit) VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + BSS-02 (Adaptor kit) STM-003 (Storm guards)	BHG-151 (Hardware) + BSS-02 (Adaptor kit) BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit JET-001, EGO-001 & BHG-151: May need to reposition clutch hose at master cylinder for additional clearance between the clamp and the hose. Due to handlebar size, an additional saddle set is required. Code: BSS-02</i>						
BMW						
F 650CS SCARVER	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-007-01-NP or STM-007-01-BK: Requires two additional M6x45 Socket Head bolts and removal of the original handlebar weight. Code: R-M6X45SHCSZP (x2)</i>						
F 650GS Single cylinder up to 2007	BHG-010 (Hardware) + JET-003 (Jet guards)		BHG-010 (Hardware) + VPS-003 (VPS guards)	BHG-010 (Hardware) + STM-003 (Storm guards)	BHG-010 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BHG-010 on Non Heated Grip models, requires an Adaptor Kit. Code: B-062</i>						
F 650GS Twin cylinder 2008 - 2012	BHG-032 (Hardware) + JET-003 (Jet guards)		BHG-032 (Hardware) + VPS-003 (VPS guards)	BHG-032 (Hardware) + STM-003 (Storm guards)	BHG-032 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) only when fitted with BHG-032 (Hardware)
<i>NOTE: BBZ-001 will only fit this model when BHG-032 hardware is installed.</i>						
F 700GS 2013 on	BHG-040 (Hardware) + JET-003 (Jet guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-040 (Hardware) + VPS-003 (VPS guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-040 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-007-01-BK (Complete kit)	BHG-040 (Hardware) + BCF-003 (Carbon guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
F 800GS 2008-2012	BHG-032 (Hardware) + JET-003 (Jet guards)		BHG-032 (Hardware) + VPS-003 (VPS guards)	BHG-032 (Hardware) + STM-003 (Storm guards)	BHG-032 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) only when fitted with BHG-032 (Hardware)
<i>NOTE: BBZ-001 will only fit this model when BHG-032 hardware is installed.</i>						
F 800GS 2013 on	BHG-040 (Hardware) + JET-003 (Jet guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-040 (Hardware) + VPS-003 (VPS guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-040 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-007-01-BK (Complete kit)	BHG-040 (Hardware) + BCF-003 (Carbon guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
F 800GSA 2014 on	BHG-040 (Hardware) + JET-003 (Jet guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-040 (Hardware) + VPS-003 (VPS guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-040 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-007-01-BK (Complete kit)	BHG-040 (Hardware) + BCF-003 (Carbon guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
F 800GT						BBZ-001 (Fabric guards)
F 800R up to 2014	STM-007-01-NP (Hardware) + JET-003 (Jet guards) NOTE: To fit STM-007-01-NP & STM-007-01-BK: It is necessary to drill and tap a 6mm thread into the head of the M12 original handlebar end bolt.		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	
F 800R 2015 on				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	
F 800S	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
F 800ST						BBZ-001 (Fabric guards)
G 450X	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)	BHG-152 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
G 650GS 2008-2010	BHG-010 (Hardware) + JET-003 (Jet guards) NOTE: To fit BHG-010 on Non Heated Grip models, requires an Adaptor Kit. Code: B-062		BHG-010 (Hardware) + VPS-003 (VPS guards)	BHG-010 (Hardware) + STM-003 (Storm guards)	BHG-010 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
G 650GS 2011 on	BHG-045 (Hardware) + JET-003 (Jet guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-045 (Hardware) + VPS-003 (VPS guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-045 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-007-01-BK (Complete kit)	BHG-045 (Hardware) + BCF-003 (Carbon guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
G 650GS SERTAO 2011 on	BHG-045 (Hardware) + JET-003 (Jet guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-045 (Hardware) + VPS-003 (VPS guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-045 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-007-01-BK (Complete kit)	BHG-045 (Hardware) + BCF-003 (Carbon guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
G 650X CHALLENGE	BHG-013 (Hardware) + JET-003 (Jet guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-013 (Hardware) + VPS-003 (VPS guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-013 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-013 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
G 650X COUNTRY	BHG-013 (Hardware) + JET-003 (Jet guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-013 (Hardware) + VPS-003 (VPS guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-013 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-013 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
G 650X MOTO	BHG-013 (Hardware) + JET-003 (Jet guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-013 (Hardware) + VPS-003 (VPS guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-013 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-013 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
HP2 ENDURO 1200 <i>2007-2009</i>	JET-002 (Complete kit)		BHG-152 (Hardware) + VPS-003 (VPS guards)	BHG-152 (Hardware) + STM-003 (Storm guards)	BHG-152 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
HP2 MEGAMOTO 1200 <i>2007-2009</i>	BHG-032 (Hardware) + JET-003 (Jet guards)		BHG-032 (Hardware) + VPS-003 (VPS guards)	BHG-032 (Hardware) + STM-003 (Storm guards)	BHG-032 (Hardware) + BCF-003 (Carbon guards)	
K 100	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
K 1200R						BBZ-001 (Fabric guards)
K 1300GT SE	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
K 1300R	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
K 1300S						BBZ-001 (Fabric guards)
K 1600GT						BBZ-001 (Fabric guards)
K 1600GTL	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
NOTE: To fit STM-007-01-BK and STM-007-01-NP: Requires two additional M8x70 Flat Head Bolts. Code: R-M8X70FHCSZP (x2)						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
R 100GS	BHG-045 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-045 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-045 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-045 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BHG-045, STM-005-01-NP, STM-005-01 BK & BBZ-001: Handguard will not fit models with original BMW Heated Grips due to wiring passing through the end of the handlebar.</i>						
R 1100GS	BHG-019 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-019 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-019 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-019 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
R 1100RS	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-007-01-NP & STM-007-01-BK: If leaving original bar end weight in place, you will require two additional M8x65mm flat head bolts. Code: R-M8X65FHCSZP (x2)</i>						
R 1150GS	BHG-019 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-019 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-019 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-019 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
R 1150GSA	BHG-019 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-019 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-019 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-019 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
R 1150R	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
R 1150RS	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-007-01-NP or STM-007-01-BK: If leaving original bar end weight in place, you will require two additional M8x65mm flat head bolts. Code: R-M8X65FHCSZP (x2)</i>						
R 1200GS <i>up to 2012</i>	BHG-032 (Hardware) + JET-003 (Jet guards)		BHG-032 (Hardware) + VPS-003 (VPS guards)	BHG-032 (Hardware) + STM-003 (Storm guards)	BHG-032 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) only when fitted with BHG-032 (Hardware)
<i>NOTE: BBZ-001 will only fit this model when BHG-032 hardware is installed.</i>						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
R 1200GS 2013 on	BHG-050 (Hardware) + JET-003 (Jet guards)		BHG-050 (Hardware) + VPS-003 (VPS guards)	BHG-050 (Hardware) + STM-003 (Storm guards)	BHG-050 (Hardware) + BCF-003 (Carbon guards)	
R 1200GSA up to 2013	BHG-032 (Hardware) + JET-003 (Jet guards)		BHG-032 (Hardware) + VPS-003 (VPS guards)	BHG-032 (Hardware) + STM-003 (Storm guards)	BHG-032 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) only when fitted with BHG-032 (Hardware)
<i>NOTE: BBZ-001 will only fit this model when BHG-032 hardware is installed.</i>						
R 1200GSA 2014 on	BHG-050 (Hardware) + JET-003 (Jet guards)		BHG-050 (Hardware) + VPS-003 (VPS guards)	BHG-050 (Hardware) + STM-003 (Storm guards)	BHG-050 (Hardware) + BCF-003 (Carbon guards)	
R 1200R 2010-2014	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit) <i>or</i> STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards) <i>or</i> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
R 1200R 2015 on	BHG-050 (Hardware) + JET-003 (Jet guards)		BHG-050 (Hardware) + VPS-003 (VPS guards)	BHG-050 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-001-00-BK (Complete kit)	BHG-050 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	
R 1200RS 2015 on	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-007-01-NP & STM-007-01-BK: If <u>removing</u> original BMW bar end weight. Mount Backbone to bar end using Mounting Position 1 & use Fitting Option B. See Instructions. If <u>retaining</u> original BMW bar end weight, Mount Backbone to bar end using Mounting Position 1 & use Fitting Option C. See Instructions. However, you will require <u>two</u> additional M8x60mm Flat Head Bolts. Code: R-M8X60FHCSZP (x2)</i>						
R 1200RT up to 2014	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
S 1000R 2013 on				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	
S 1000XR 2015 on	BHG-050 (Hardware) + JET-003 (Jet guards)		BHG-050 (Hardware) + VPS-003 (VPS guards)	BHG-050 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-001-00-BK (Complete kit)	BHG-050 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	
<i>NOTE: To fit BHG-050: Due to electrical switch below clutch assembly, handguard will need to be positioned lower. Therefore, wind protection will be slightly decreased.</i>						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
BUELL						
XB 12X ULYSSES	JET-001 (Complete kit) <i>or</i> Weather protection only, fit STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-151 (Hardware) + VPS-003 (VPS guards) <i>or</i> Weather protection only, fit STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards) <i>or</i> Weather protection only, fit STM-005-01-BK (Complete kit)	BHG-151 (Hardware) + BCF-003 (Carbon guards) <i>or</i> Weather protection only, fit STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
CAN AM						
SPYDER <i>up to 2012</i>	STM-005-01-NP (Hardware) + JET-003 (Jet guards) <i>NOTE: To fit STM-005-01-NP, STM-005-01-BK & BBZ-001: Handguards may touch screen and obscure mirrors on some models.</i>		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
SPYDER <i>2013 on</i>	STM-007-01-NP (Hardware) + JET-003 (Jet guards) <i>NOTE: To fit STM-005-01-NP, STM-005-01-BK & BBZ-001: Handguards may touch screen and obscure mirrors on some models.</i>		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
DUCATI						
DIAVEL 1200	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
MONSTER 620 IE				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
MONSTER 696	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
MONSTER 1000 S4RS	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
MONSTER 1200 <i>2014 on</i>	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
MONSTER 1200S <i>2014 on</i>	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
MULTISTRADA 1000DS	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit) <i>or</i> STM-001-00-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards) <i>or</i> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
MULTISTRADA 1100DS	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit) or STM-001-00-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards) or STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
MULTISTRADA 1200 2010-2012			BLG-012 (Hardware) + (no plastics available)			
<i>NOTE: To fit BLG-012: Designed to fit around original Ducati Handguard. NO plastic guard option available.</i>						
MULTISTRADA 1200 2013-2014			BLG-013 (Hardware) + (no plastics available)			
<i>NOTE: To fit BLG-013: Designed to fit around original Ducati Handguard. NO plastic guard option available.</i>						
SCRAMBLER Classic 2015 on	BHG-060 (Hardware) + JET-003 (Jet guards)		BHG-060 (Hardware) + VPS-003 (VPS guards)	BHG-060 (Hardware) + STM-003 (Storm guards)	BHG-060 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
SCRAMBLER Icon 2015 on	BHG-060 (Hardware) + JET-003 (Jet guards)		BHG-060 (Hardware) + VPS-003 (VPS guards)	BHG-060 (Hardware) + STM-003 (Storm guards)	BHG-060 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
SCRAMBLER Urban Enduro 2015 on	BHG-060 (Hardware) + JET-003 (Jet guards)		BHG-060 (Hardware) + VPS-003 (VPS guards)	BHG-060 (Hardware) + STM-003 (Storm guards)	BHG-060 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
STREET FIGHTER 848	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
SUPERSPORT 750						BBZ-001 (Fabric guards)
GAS GAS						
EC models	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) or VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)	BHG-152 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GILERA						
FUOCO 500	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
HARLEY DAVIDSON						
SPORTSTER 883	STM-005-01-NP (Hardware) + B-074 (Adaptor kit) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + B-074 (Adaptor kit) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit) + B-074 (Adaptor kit)	STM-005-01-NP (Hardware) + B-074 (Adaptor kit) + BCF-003 (Carbon guards)	
SPORTSTER 1200	STM-005-01-NP (Hardware) + B-074 (Adaptor kit) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + B-074 (Adaptor kit) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit) + B-074 (Adaptor kit)	STM-005-01-NP (Hardware) + B-074 (Adaptor kit) + BCF-003 (Carbon guards)	

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
V-ROD 1250	STM-005-01-NP (Hardware) + B-074 (Adaptor kit) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + B-074 (Adaptor kit) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit) + B-074 (Adaptor kit)	STM-005-01-NP (Hardware) + B-074 (Adaptor kit) + BCF-003 (Carbon guards)	
HONDA						
CB 125E	BHG-055 (Hardware) + JET-003 (Jet guards)		BHG-055 (Hardware) + VPS-003 (VPS guards)	BHG-055 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-001-00-BK (Complete kit)	BHG-055 (Hardware) + BCF-003 (Carbon guards) <u>or</u> Weather protection only, fit STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
CB 250				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
CB 400 <i>1992 on</i>				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
CB 500F <i>2013 on</i>	BHG-055 (Hardware) + JET-003 (Jet guards)		BHG-055 (Hardware) + VPS-003 (VPS guards)	BHG-055 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-001-00-BK (Complete kit)	BHG-055 (Hardware) + BCF-003 (Carbon guards) <u>or</u> Weather protection only, fit STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BHG-055 & BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
CB 500R <i>2013 on</i>						BBZ-001 (Fabric guards)
<i>NOTE: To fit BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
CB 500X <i>2013 on</i>	BHG-046 (Hardware) + JET-003 (Jet guards) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-046 (Hardware) + VPS-003 (VPS guards) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-046 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-005-01-BK (Complete kit)	BHG-046 (Hardware) + BCF-003 (Carbon guards) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BHG-046, STM-005-01-NP, STM-005-01-BK or BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
CB 600F (HORNET) <i>2007 on</i>				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
CB 650F	BHG-055 (Hardware) + JET-003 (Jet guards)		BHG-055 (Hardware) + VPS-003 (VPS guards)	BHG-055 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-001-00-BK (Complete kit)	BHG-055 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BHG-055 & BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
CB 750 <i>1992 - 1999</i>				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
CB 900F (HORNET)				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
CB 1000R (ABS) <i>up to 2012</i>	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
CB 1000R (non ABS) <i>up to 2012</i>				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
CB 1100 <i>2011 on</i>				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
CB 1300 (naked)				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
CB 1300S				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
CBF 125				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
CBF 600S (faired)				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-001-00-NP & STM-001-00-BK: Drilling extra hole in black plastic L Bracket is recommended. This will bring handguard 15mm closer to handlebar which will reduce fouling on screen/fairing. Full lock still slightly reduced.</i>						
CBF 1000 <i>up to 2009</i>				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-001-00-NP & STM-001-00-BK: The handguard will touch the windscreen. To reduce the interference, drill an additional hole in the mounting bracket to relocate the handguard 15mm closer to the handlebar. The handlebar also needs to be rolled back 5-10mm</i>						
CBR 250 <i>2011-2013</i>						BBZ-001 (Fabric guards)
CBR 300 <i>2014 on</i>						BBZ-001 (Fabric guards)
CR 80R		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
CR 85R		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
CR 85R EXPERT		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
CR 125R	JET-001 (Complete kit)	EGO-001 (Complete kit)	VPS-007 (MX complete kit)			
CRF 50F		BLG-018 (Hardware) <i>(no plastics available)</i>				
CRF 70F			VPS-007 (MX complete kit)			
CRF 80F		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
CRF 100F		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
CRF 125F		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
2014 on	NOTE: To fit EGO-004: May require repositioning of the brake hose, at the master cylinder Banjo Bolt, for inner clamp clearance.					
CRF 150F		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
CRF 150R		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
CRF 150R EXPERT		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
CRF 230F	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
CRF 230L	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
CRF 250L 2012 on	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
CRF 250R 22mm (7/8") handlebar	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		
CRF 250R tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		
CRF 250X 22mm (7/8") handlebar	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
CRF 250X tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		
CRF 450R 22mm (7/8") handlebar	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		
CRF 450R tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		
CRF 450X 22mm (7/8") handlebar	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		
CRF 450X tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		
CRF 1000L AFRICA TWIN non DCT model 2016 on	BHG-062 (Hardware) + JET-003 (Jet guards)		BHG-062 (Hardware) + VPS-003 (VPS guards)	BHG-062 (Hardware) + STM-003 (Storm guards)	BHG-062 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) only when fitted with BHG-062 (Hardware) +
<i>NOTE: BBZ-001 will only fit this model when BHG-061 hardware is installed.</i>						
CRF 1000L AFRICA TWIN DCT model 2016 on	BHG-062 (Hardware) + JET-003 (Jet guards)		BHG-062 (Hardware) + VPS-003 (VPS guards)	BHG-062 (Hardware) + STM-003 (Storm guards)	BHG-062 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) only when fitted with BHG-062 (Hardware)
<i>NOTE: BBZ-001 will only fit this model when BHG-062 hardware is installed.</i>						
CTX 700				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
CTX 700D						BBZ-001 (Fabric guards)
<i>NOTE: To fit BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
CTX 700N				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
CTX 1300						BBZ-001 (Fabric guards)
<i>NOTE: To fit BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
FSC 600 SILVERWING						BBZ-001 (Fabric guards)
NC 700D INTEGRA	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-005-01-NP, STM-005-01-BK & BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
NC 700S DCT model						BBZ-001 (Fabric guards)
<i>NOTE: To fit BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
NC 700S non DCT model				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
NC 700X DCT model	BHG-046 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-046 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-046 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-046 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BHG-046, STM-005-01-NP, STM-005-01-BK & BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
NC 700X non DCT model	BHG-046 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-046 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-046 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-046 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BHG-046, STM-005-01-NP, STM-005-01-BK & BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
NC 750D INTEGRA	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-005-01-NP, STM-005-01-BK or BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
NC 750S DCT model						BBZ-001 (Fabric guards)
<i>NOTE: To fit BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
NC 750S non DCT model				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
NC 750X DCT model	BHG-046 (Hardware) + JET-003 (Jet guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-046 (Hardware) + VPS-003 (VPS guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-046 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-046 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BHG-046, STM-005-01-NP, STM-005-01-BK or BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
NC 750X non DCT model	BHG-046 (Hardware) + JET-003 (Jet guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-046 (Hardware) + VPS-003 (VPS guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-046 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-046 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BHG-046, STM-005-01-NP, STM-005-01-BK or BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
NSA 700 DN-01	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
NT 650						BBZ-001 (Fabric guards)
NT 700V						BBZ-001 (Fabric guards)
NTV 650 REVERE	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
NX 650 DOMINATOR	JET-001 (Complete kit)		BHG-151 (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards)	BHG-151 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
PCX 125	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit) <i>or</i> STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards) <i>or</i> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
SH 300i	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
VFR 800						BBZ-001 (Fabric guards)
VFR 800X CROSSRUNNER <i>up to 2014</i>	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-007-01-NP & STM-007-01 BK: The handguard may touch the instruments at full lock. To avoid this, bend the handguard backbone closer to the handlebar.</i>						
VFR 800X CROSSRUNNER <i>2015 on</i>						BBZ-001 (Fabric guards)
<i>NOTE: To fit BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
VFR 1200X CROSSTOURER	BHG-046 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-046 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-046 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-046 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
VT 400C SAVAGE				STM-002-00-BK (Complete kit)	STM-002-00-NP (Hardware) + BCF-003 (Carbon guards)	
VT 750C SHADOW				STM-002-00-BK (Complete kit)	STM-002-00-NP (Hardware) + BCF-003 (Carbon guards)	
VTR 250 <i>1998 on</i>				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
XL 125V VARADERO						BBZ-001 (Fabric guards)
XL 600V TRANSALP	BHG-018 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-018 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-018 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-018 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BHG-018, STM-005-01-NP, STM-005-01-BK or BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
XL 650V TRANSALP	BHG-018 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-018 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-018 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-018 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BHG-018, STM-005-01-NP, STM-005-01-BK or BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
XL 700V TRANSALP	BHG-018 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-018 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-018 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-018 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BHG-018, STM-005-01-NP, STM-005-01-BK or BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
XL 1000V VARADERO	BHG-046 (Hardware) + JET-003 (Jet guards)		BHG-046 (Hardware) + VPS-003 (VPS guards)	BHG-046 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-001-00-BK (Complete kit)	BHG-046 (Hardware) + BCF-003 (Carbon guards) <u>or</u> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit BHG-046 or BBZ-001: Requires the removal of original external and internal bar weights. This will leave a hollow handlebar for mounting handguard.</i>						
XLV 750 AFRICA TWIN	JET-001 (Complete kit)		BHG-151 (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards)	BHG-151 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
XR 250	JET-001 (Complete kit)		BHG-151 (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
XR 400	JET-001 (Complete kit)		BHG-151 (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
XR 650L	JET-001 (Complete kit)		BHG-151 (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
XR 650R	JET-001 (Complete kit)		BHG-151 (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
HUSABERG						
ALL MODELS	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
HUSQVARNA						
701 ENDURO 2016 on	BHG-052 (Hardware) + JET-003 (Jet guards)		BHG-052 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-052 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
701 SUPERMOTO 2016 on	BHG-052 (Hardware) + JET-003 (Jet guards)		BHG-052 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-052 (Hardware) + STM-003 (Storm guards)	BHG-152 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
CR all models			VPS-007 (MX complete kit)			BBZ-001 (Fabric guards)
SM tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)	BHG-152 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit JET-002, EGO-005, BHG-152 & BBZ-001: Some 2010-2011 models have a 10mm internal handlebar size and will require an adaptor kit. Code: B-025</i>						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
TC all models			VPS-007 (MX complete kit)			BBZ-001 (Fabric guards)
TE 22mm (7/8") Tommaselli handlebar	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
<i>NOTE: To fit JET-001, EGO-001, BHG-151 & BBZ-001: Some early models with 12mm internal handlebar size may require bar end kit. Code: B-029</i>						
TE tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
TR 650 TERRA 2013 on	BHG-051 (Hardware) + JET-003 (Jet guards)		BHG-051 (Hardware) + VPS-003 (VPS guards)	BHG-051 (Hardware) + STM-003 (Storm guards)	BHG-051 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
TR 650 STRADA 2013 on	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
WR 22mm (7/8") Tommaselli handlebar	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
<i>NOTE: To fit JET-001, EGO-001, BHG-151 & BBZ-001: To fit some early models with 12mm internal handlebar size may require bar end kit. Code: B-029</i>						
WR tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
HYOSUNG						
GT 250				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GT 250S	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-007-01-NP & STM-007-01-BK: May need to bend backbone inward at the inside end by 10mm for fairing clearance.</i>						
GT 650L COMET				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GT 650S	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-007-01-NP & STM-007-01-BK: May need to bend backbone inward at the inside end by 10mm for fairing clearance.</i>						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
GV 650 AQUILA	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
KAWASAKI						
EN-650B (VULCAN S) 2015 on	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
ER-5 500	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
ER-6F (Ninja 650) 2006 - 2008						BBZ-001 (Fabric guards)
ER-6F (Ninja 650) 2009 on				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-001-00-NP & STM-001-00-BK: The handguard will touch the windscreen. To reduce the interference, drill an additional hole in the black plastic L bracket to relocate the handguard 15mm closer to the handlebar.</i>						
ER-6N (650 Naked) all ABS	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
ER-6N (650 Naked) all non-ABS	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit) or STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards) or STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
EX 300 (NINJA 300) 2013 on						BBZ-001 (Fabric guards)
KL 250 SUPER SHERPA	JET-001 (Complete kit)		BHG-151 (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
KLE 500	JET-001 (Complete kit)		BHG-151 (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards)	BHG-151 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: Handlebar end plug will need to be drilled and tapped to M8 x 1.25mm thread (except when fitting BBZ-001)</i>						
<i>or</i>						
<i>Weather protection only, fit</i>						
	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	
<i>NOTE: Handlebar end plug will need to be drilled and tapped to M8 x 1.25mm thread.</i>						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
KLE 650 (VERSYS) all	BHG-034 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-034 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-034 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-034 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
KLE 1000 (VERSYS) up to 2014	BHG-046 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-046 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-046 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-046 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
KLE 1000 (VERSYS) 2015 on	JET-002 (Complete kit) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-152 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-152 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
KLR 650 All models	JET-001 (Complete kit) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-151 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
KLX 100		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
<i>NOTE: To fit EGO-004: Lever/controls will need to be moved in, to allow lever to handguard clearance.</i>						
KLX 110		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
<i>NOTE: To fit EGO-004: Lever/controls will need to be moved in, to allow lever to handguard clearance.</i>						
KLX 140	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		
<i>NOTE: To fit EGO-001: Lever/controls will need to be moved in, to allow lever to handguard clearance.</i>						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
KLX 140L	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		
<i>NOTE: To fit EGO-001: Lever/controls will need to be moved in, to allow lever to handguard clearance.</i>						
KLX 150 2014 on	BHG-058 (Hardware) + JET-003 (Jet guards)		BHG-058 (Hardware) + VPS-003 (VPS guards)			BBZ-001 (Fabric guards)
<i>NOTE: To fit BHG-058 & BBZ-001: Handlebar end plug will need to be drilled and tapped to M8 x 1.25mm thread.</i>						
KLX 250 1986-2006	JET-001 (Complete kit)		BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
KLX 250A 1986-2007	JET-001 (Complete kit)		BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
<i>NOTE: To fit JET-001, BHG-151 & BBZ-001: Handlebar end plug may need to be drilled and tapped to M8 x 1.25mm thread.</i>						
KLX 250S SFF/TFF	JET-001 (Complete kit)		BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)	BHG-151 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit JET-001, BHG-151 & BBZ-001: Handlebar end plug will need to be drilled and tapped to M8 x 1.25mm thread.</i>						
KLX 450 2008 on	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
KX 65		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
KX 80		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
KX 85		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
KX 125	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		
KX 250	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
KX 250F	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		
KX 450F	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		
VN 750 VULCAN				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	
VN 900 CLASSIC				STM-002-00-BK (Complete kit)	STM-002-00-NP (Hardware) + BCF-003 (Carbon guards)	
VN 900 VULCAN CUSTOM				STM-002-00-BK (Complete kit)	STM-002-00-NP (Hardware) + BCF-003 (Carbon guards)	
Z 250SL 2014 on	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-005-01-NP, STM-005-01-BK & BBZ-001: To fit handguard requires the removal of original external and internal bar weights.</i>						
Z 750 up to 2008	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit) <u>or</u> STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards) <u>or</u> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
Z 750 2009 on	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
Z 800 2012 on				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
Z 1000 2003-2006	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit) <u>or</u> STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards) <u>or</u> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-007-01-NP & STM-007-01-BK: Handguard backbone may need to be bent outward at inside end by 10-15mm for control clearance.</i>						
Z 1000 2007-2009	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-007-01-NP & STM-007-01-BK: Handguard backbone may need to be bent outward at inside end by 10-15mm for control clearance.</i>						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
Z 1000 2010-2013	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-007-01-NP & STM-007-01-BK: Handguard backbone may need to be bent outward at inside end by 10-15mm for control clearance.</i>						
Z 1000 2014 on	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-007-01-NP & STM-007-01-BK: Handguard backbone may need to be bent outward at inside end by 10-15mm for control clearance.</i>						
Z 1000SX NINJA 2010 on						BBZ-001 (Fabric guards)
ZRX 1100	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
ZRX 1200	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
ZX-14/ZZR1400						BBZ-001 (Fabric guards)
KTM						
65 SX		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
85 SX with tapered handlebar 2013 on	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		
200 DUKE 2013 on	BHG-055 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-055 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-055 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-055 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
250 FREERIDE	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
350 FREERIDE	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
390 DUKE 2013 on	BHG-055 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-055 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-055 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-055 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
NOTE: To fit STM-007-01-NP & STM-007-01-BK : Remove original handlebar end weight and use Fitting Option A from the instructions.						
690 DUKE 2012 on	JET-002 (Complete kit) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-152 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-152 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
NOTE: To fit JET-002 & BHG-152 : KTM 690 Duke models with radial brake master cylinder, require additional Space & Bolt Kit for brake lever clearance. Code: B-079						
690 ENDURO	JET-002 (Complete kit)		BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
690 ENDURO R	JET-002 (Complete kit)		BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
950 LC 8 2003-2005	JET-002 (Complete kit) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-152 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-152 (Hardware) + BCF-003 (Carbon guards) + <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
950 LC 8 ADVENTURE 2003-2005	JET-002 (Complete kit) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-152 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-152 (Hardware) + BCF-003 (Carbon guards) + <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
990 LC 8 2006-2013	JET-002 (Complete kit) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-152 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-005-01-BK (Complete kit)	BHG-152 (Hardware) + BCF-003 (Carbon guards) + <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
990 LC 8 ADVENTURE 2006-2013	JET-002 (Complete kit) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-152 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-005-01-BK (Complete kit)	BHG-152 (Hardware) + BCF-003 (Carbon guards) + <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
1050 ADVENTURE	JET-002 (Complete kit) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-152 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-005-01-BK (Complete kit)	BHG-152 (Hardware) + BCF-003 (Carbon guards) + <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
1190 ADVENTURE	JET-002 (Complete kit) + B-079 (Spacer & Bolt) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-152 (Hardware) + VPS-003 (VPS guards) B-079 (Spacer & Bolt) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-152 (Hardware) + STM-003 (Storm guards) + B-079 (Spacer & Bolt) <u>or</u> Weather protection only, fit STM-005-01-BK (Complete kit)	BHG-152 (Hardware) + BCF-003 (Carbon guards) + B-079 (Spacer & Bolt) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
NOTE: To fit JET-002 & BHG-152: Requires additional spacer and bolt kit for extra brake clearance on the right side between the clamp and the backbone. Code: B-079						
1190 ADVENTURE R	JET-002 (Complete kit) + B-079 (Spacer & Bolt) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-152 (Hardware) + VPS-003 (VPS guards) B-079 (Spacer & Bolt) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-152 (Hardware) + STM-003 (Storm guards) + B-079 (Spacer & Bolt) <u>or</u> Weather protection only, fit STM-005-01-BK (Complete kit)	BHG-152 (Hardware) + BCF-003 (Carbon guards) + B-079 (Spacer & Bolt) <u>or</u> Weather protection only, fit STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
NOTE: To fit JET-002 & BHG-152: Requires additional spacer and bolt kit for extra brake clearance on the right side between the clamp and the backbone. Code: B-079						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
1290 SUPER ADVENTURE	JET-002 (Complete kit) + B-079 (Spacer & Bolt) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-152 (Hardware) + VPS-003 (VPS guards) B-079 (Spacer & Bolt) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-152 (Hardware) + STM-003 (Storm guards) + B-079 (Spacer & Bolt) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-152 (Hardware) + BCF-003 (Carbon guards) + B-079 (Spacer & Bolt) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit JET-002 & BHG-152: Requires additional spacer and bolt kit for extra brake clearance on the right side between the clamp and the backbone. Code: B-079</i>						
1290 SUPER DUKE R <i>2014 on</i>	BHG-054 (Hardware) + JET-003 (Jet guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-054 (Hardware) + VPS-003 (VPS guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-054 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-054 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
EXC	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <i>or</i> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
EXC-F	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <i>or</i> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
EXC-W	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <i>or</i> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
EXC SIX DAYS	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <i>or</i> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
LC 4 tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <i>or</i> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
SX over 125CC with tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <i>or</i> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
SX-F over 125CC and with tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <i>or</i> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		
XC	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <i>or</i> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
XC-F	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <i>or</i> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
XC-W	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <i>or</i> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
KYMCO						
XCITING 500 RI	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-007-01-NP & STM-007-01-BK: Requires two additional M8x60mm Flat Head bolts. Use locktight. Code: R-M8X60FHCSZP (x2).</i>						
MOTO GUZZI						
BREVA 750 IE	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
NTX 1200 STELVIO	BHG-033 (Hardware) + JET-003 (Jet guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-033 (Hardware) + VPS-003 (VPS guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-033 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-033 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
V7 CLASSIC				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
OSET						
20 INCH			VPS-007 (MX complete kit)			
PIAGGIO						
MP3 SCOOTER	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
SHERCO						
SE <i>2010 on</i>	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
SEF <i>2010 on</i>	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
SUZUKI						
AN 400 BURGMAN	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
AN 650 BURGMAN						BBZ-001 (Fabric guards)
DL 650 V-STROM	BHG-046 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-046 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-046 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-046 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
DL 1000 V-STROM	BHG-046 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)		BHG-046 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-046 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-046 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
DR 200SE	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
DR 350	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
DR 650SE	JET-001 (Complete kit)		BHG-151 (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
DRZ 70		BLG-018 (Hardware) <i>(no plastics available)</i>				
DRZ 125L	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
DRZ 250	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
DRZ 400E	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
DRZ 400S	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
DRZ 400SM 22mm (7/8") handlebar	JET-001 (Complete kit) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-151 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-151 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
DRZ 400SM tapered handlebar	JET-002 (Complete kit) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + JET-003 (Jet guards)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-152 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-BK (Complete kit)	BHG-152 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GS 500E <i>1989 on</i>				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GSF 600N BANDIT <i>1996-2005</i>				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GSF 650N BANDIT <i>2005 on</i>				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GSF 1200N BANDIT - Naked				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GSF 1250N BANDIT - Naked				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GSR 600 <i>2006-2008</i>				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GSX 650F						BBZ-001 (Fabric guards)
GSX 1200 BANDIT						BBZ-001 (Fabric guards)
GSX 1250 BANDIT						BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
GSX 1250FA						BBZ-001 (Fabric guards)
GSX 1300 B-KING	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GSX 1300R HAYABUSA						BBZ-001 (Fabric guards)
GSX 1400 2001-2008				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GSXR 600						BBZ-001 (Fabric guards)
GSXR 750						BBZ-001 (Fabric guards)
GSXR 1000						BBZ-001 (Fabric guards)
GSXR 1100						BBZ-001 (Fabric guards)
GSXS 1000 2015 on	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GSXS 1000SF 2015 on	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GW 250 INAZUMA	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
GZ 125 MARAUDER				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
RM 80		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
RM 85		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
RM 85L		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
RM 125	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		
RM 250	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		
RMX 450Z	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		
RMZ 250 22mm (7/8") handlebar	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
RMZ 250 tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		
RMZ 450 22mm (7/8") handlebar	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		
RMZ 450 tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		
SFV 650 GLADIUS 2009	BHG-055 (Hardware) + JET-003 (Jet guards)		BHG-055 (Hardware) + VPS-003 (VPS guards)	BHG-055 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-001-00-BK (Complete kit)	BHG-055 (Hardware) + BCF-003 (Carbon guards) <u>or</u> Weather protection only, fit STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
SV 650 1999-2008				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
SV 650S - Faired						BBZ-001 (Fabric guards)
SV 1000 CLASSIC 2003-2009				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
SV 1000 NAKED 2003-2008				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
VL 250 INTRUDER	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit) <u>or</u> STM-001-00-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards) <u>or</u> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
VL 800 C50				STM-002-00-BK (Complete kit)	STM-002-00-NP (Hardware) + BCF-003 (Carbon guards)	

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
SWM						
RS 300R 2015 on	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
RS 500R 2015 on	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
RS 650R 2015 on	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
SM 500R 2015 on	JET-002 (Complete kit) + B-079 (Spacer & Bolt)		BHG-152 (Hardware) + VPS-003 (VPS guards) + B-079 (Spacer & Bolt) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards) + B-079 (Spacer & Bolt)	BHG-152 (Hardware) + BCF-003 (Carbon guards) + B-079 (Spacer & Bolt)	BBZ-001 (Fabric guards)
<i>NOTE: To fit JET-002 & BHG-152: Requires additional spacer and bolt kit for extra brake clearance on the right side between the clamp and the backbone. Code: B-079</i>						
SM 650R 2015 on	JET-002 (Complete kit) + B-079 (Spacer & Bolt)		BHG-152 (Hardware) + VPS-003 (VPS guards) + B-079 (Spacer & Bolt) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards) + B-079 (Spacer & Bolt)	BHG-152 (Hardware) + BCF-003 (Carbon guards) + B-079 (Spacer & Bolt)	BBZ-001 (Fabric guards)
<i>NOTE: To fit JET-002 & BHG-152: Requires additional spacer and bolt kit for extra brake clearance on the right side between the clamp and the backbone. Code: B-079</i>						
TM						
EN Reikon tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
MX			VPS-007 (MX complete kit)			
SEM Reikon tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
TRIUMPH						
BONNEVILLE SE 2009-2010				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
BONNEVILLE T100						BBZ-001 (Fabric guards)
DAYTONA 675						BBZ-001 (Fabric guards)
ROCKET 3	STM-007-01-NP (Hardware) + JET-003 (Jet guards) <i>NOTE: To fit STM-007-01-NP & STM-007-01-BK: Requires two additional M6 x 85mm Socket Head bolts.</i>		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
SCRAMBLER 900				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
SPEED MASTER	STM-007-01-NP (Hardware) + JET-003 (Jet guards) <i>NOTE: To fit STM-007-01-NP & STM-007-01-BK: Recommend drill and tap handlebar end to M6 or M8 if M5 thread is standard.</i>		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
SPEED TRIPLE with Fixed Thread Handlebar End	STM-007-01-NP (Hardware) + JET-003 (Jet guards) <i>NOTE: To fit STM-007-01-NP & STM-007-01-BK: Recommend drill and tap handlebar end to M6 or M8 if M5 thread is standard (for all models up to 2012).</i>		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
SPEED TRIPLE with Hollow Handlebar End	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
SPRINT GT						BBZ-001 (Fabric guards)
SPRINT RS	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
STREET TRIPLE	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit) or STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards) or STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
	<i>NOTE: To fit STM-007-01-NP & STM-007-01-BK: Recommend drill and tap handlebar end to M6 or M8 if M5 thread is standard (up to 2013 models).</i>					
STREET TRIPLE R	STM-007-01-NP (Hardware) + JET-003 (Jet guards) <i>NOTE: To fit STM-007-01-NP & STM-007-01-BK: Recommend drill and tap handlebar end to M6 or M8 if M5 thread is standard.</i>		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
STREET TRIPLE 660	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
THUNDERBIRD	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit) <u>or</u> STM-002-00-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards) <u>or</u> STM-002-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
TIGER 800 <i>up to 2014</i>	BHG-059 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-059 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-059 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-059 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
TIGER 800XC <i>all models</i>	BHG-059 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-059 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-059 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-059 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
TIGER 800XCA <i>2015 on</i>	BHG-059 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-059 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-059 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-059 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
TIGER 800XCX <i>2015 on</i>	BHG-059 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-059 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-059 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-059 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
TIGER 800XR <i>2015 on</i>	BHG-059 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-059 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-059 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-059 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
TIGER 800XRT 2015 on	BHG-059 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-059 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-059 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-059 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
TIGER 800XRX 2015 on	BHG-059 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-059 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-059 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-059 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
TIGER 900i 1999-2001	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit) <u>or</u> STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards) <u>or</u> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
TIGER 955i	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit) <u>or</u> STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards) <u>or</u> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
TIGER 1050	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit) <u>or</u> STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards) <u>or</u> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
TIGER 1050 SPORT 2013 on	BHG-032 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-032 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-032 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-032 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
TIGER 1200 EXPLORER	BHG-059 (Hardware) + JET-003 (Jet guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-059 (Hardware) + VPS-003 (VPS guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-059 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-059 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
TIGER 1200 EXPLORER SPOKED	BHG-059 (Hardware) + JET-003 (Jet guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-059 (Hardware) + VPS-003 (VPS guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-059 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-059 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
TIGER 1200 EXPLORER XC	BHG-059 (Hardware) + JET-003 (Jet guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-059 (Hardware) + VPS-003 (VPS guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-059 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-059 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
URAL						
URAL all models (2007 on) with 22mm (7/8") handlebar	BHG-046 (Hardware) + JET-003 (Jet guards)		BHG-046 (Hardware) + VPS-003 (VPS guards)	BHG-046 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-001-00-BK (Complete kit)	BHG-046 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: BHG-046 is not suitable for sidecar bikes with sidecar windshield.</i>						
VESPA						
SUPER 125GT	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
YAMAHA						
FJ 09 (MT 09 TRACER) 2015 on United States of America	BHG-052 (Hardware) + JET-003 (Jet guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + JET-003 (Jet guards) NOTE: To fit BHG-052: Remove original handguard and retain M8 Washer. Use M8 Washer in place of items 8 & 9 in the instructions.		BHG-052 (Hardware) + VPS-003 (VPS guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-052 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-007-01-BK (Complete kit)+	BHG-052 (Hardware) + BCF-003 (Carbon guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) +
FJR 1300	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
FZ 09 (MT 09) 2013 on United States of America	BHG-052 (Hardware) + JET-003 (Jet guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + JET-003 (Jet guards) NOTE: To fit STM-007-01-NP, STM-007-01-BK & BBZ-001: Remove original bar end weight and insert threaded adaptor. Code: B-083		BHG-052 (Hardware) + VPS-003 (VPS guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + VPS-003 (VPS guards)	BHG-052 (Hardware) + STM-003 (Storm guards) <u>or</u> Weather protection only, fit STM-007-01-BK (Complete kit)+ B-083 (Threaded adaptor)	BHG-052 (Hardware) + BCF-003 (Carbon guards) <u>or</u> Weather protection only, fit STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) + B-083 (Threaded adaptor)
FZ 1 1000 2006 on	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + JET-003 (Jet guards) NOTE: To fit STM-007-01-NP, STM-007-01-BK & BBZ-001: Remove original bar end weight and insert threaded adaptor. Code: B-083		STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)+ B-083 (Threaded adaptor) <u>or</u> STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + BCF-003 (Carbon guards) <u>or</u> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) + B-083 (Threaded adaptor)
FZ 1N 1000 2001 on	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + JET-003 (Jet guards) NOTE: To fit STM-007-01-NP, STM-007-01-BK & BBZ-001: Remove original bar end weight and insert threaded adaptor. Code: B-083		STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)+ B-083 (Threaded adaptor) <u>or</u> STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + BCF-003 (Carbon guards) <u>or</u> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) + B-083 (Threaded adaptor)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
FZ 1S 1000 2006 on	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)+ B-083 (Threaded adaptor) or STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + BCF-003 (Carbon guards) or STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) + B-083 (Threaded adaptor)
<i>NOTE: To fit STM-007-01-NP, STM-007-01-BK & BBZ-001: Remove original bar end weight and insert threaded adaptor. Code: B-083</i>						
FZ 6 - FAZER 600 2004 on	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)+ B-083 (Threaded adaptor) or STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + BCF-003 (Carbon guards) or STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) + B-083 (Threaded adaptor)
<i>NOTE: To fit STM-007-01-NP, STM-007-01-BK & BBZ-001: Remove original bar end weight and insert threaded adaptor. Code: B-083</i>						
FZ 6R 600 2009 on	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)+ B-083 (Threaded adaptor)	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) + B-083 (Threaded adaptor)
<i>NOTE: To fit STM-007-01-NP, STM-007-01-BK & BBZ-001: Remove original bar end weight and insert threaded adaptor. Code: B-083</i>						
FZ 8 800 2011 on	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit) or STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards) or STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
FZS 1000 2001-2005				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	
MT O1 1700 2006				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	
MT 03 2006-2013	STM-007-01-NP (Hardware) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)	STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
<i>NOTE: To fit STM-007-01-NP, STM-007-01-BK: Requires two additional M8 x 90mm Flat Head bolts if fitting to the outside of the bar end weight. Code: R-M8x90FHCSZP (x2)</i>						
MT 07 2014 on	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit) B-083 (Threaded adaptor)	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) + B-083 (Threaded adaptor)
<i>NOTE: To fit STM-007-01-NP, STM-007-01-BK & BBZ-001: Remove original bar end weight and insert threaded adaptor. Code: B-083</i>						

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
MT 09 (FZ 09) 2013 on	BHG-052 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + JET-003 (Jet guards)		BHG-052 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + VPS-003 (VPS guards)	BHG-052 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)+ B-083 (Threaded adaptor)	BHG-052 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) + B-083 (Threaded adaptor)
<i>NOTE: To fit STM-007-01-NP, STM-007-01-BK & BBZ-001: Remove original bar end weight and insert threaded adaptor. Code: B-083</i>						
MT 09 TRACER (FJ 09) 2014 on	BHG-052 (Hardware) + JET-003 (Jet guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-052 (Hardware) + VPS-003 (VPS guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-052 (Hardware) + STM-003 (Storm guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)+	BHG-052 (Hardware) + BCF-003 (Carbon guards) <u>or</u> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) +
<i>NOTE: To fit BHG-052: Remove original handguard and retain M8 Washer. Use M8 Washer in place of items 8 & 9 in the instructions.</i>						
TDM 850	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	
TDM 900 2002 on	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)+ B-083 (Threaded adaptor) <u>or</u> STM-001-00-BK (Complete kit)	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + BCF-003 (Carbon guards) <u>or</u> STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) + B-083 (Threaded adaptor)
<i>NOTE: To fit STM-007-01-NP, STM-007-01-BK & BBZ-001: Remove original bar end weight and insert threaded adaptor. Code: B-083</i>						
TTR 90	BHG-039 (Hardware) + JET-003 (Jet guards)		BHG-039 (Hardware) + VPS-003 (VPS guards)			
TTR 110	BHG-039 (Hardware) + JET-003 (Jet guards)		BHG-039 (Hardware) + VPS-003 (VPS guards)			
TTR 110E	BHG-039 (Hardware) + JET-003 (Jet guards)		BHG-039 (Hardware) + VPS-003 (VPS guards)			
TTR 125E	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
TTR 230	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
TTR 250	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
TW 200	JET-001 (Complete kit)		BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
WR 250F 22mm (7/8") handlebar	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
WR 250F tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
WR 250R	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
WR 250X	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
WR 400	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
WR 450F 22mm (7/8") handlebar	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
WR 450F tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
XJ 6 600 2008-2009				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	
XJ 600 DIVERSION				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	
<i>NOTE: To fit STM-001-00-NP & STM-001-00-BK: Drilling an extra hole in black plastic L Bracket is recommended. This will bring handguard 15mm closer to handlebar which will reduce fouling with screen/fairing. Full lock still slightly reduced.</i>						
XJR 1300 Up to 2014				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	
XJR 1300 2015 on	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit)+ B-083 (Threaded adaptor)	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) + B-083 (Threaded adaptor)
<i>NOTE: To fit STM-007-01-NP, STM-007-01-BK & BBZ-001: Remove original bar end weight and insert threaded adaptor. Code: B-083</i>						
XP 500 T-MAX						BBZ-001 (Fabric guards) + B-083 (Threaded adaptor)
XSR 700 2016 on	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + JET-003 (Jet guards)		STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + VPS-003 (VPS guards)	STM-007-01-BK (Complete kit) B-083 (Threaded adaptor)	STM-007-01-NP (Hardware) + B-083 (Threaded adaptor) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards) + B-083 (Threaded adaptor)
<i>NOTE: To fit STM-007-01-NP, STM-007-01-BK & BBZ-001: Remove original bar end weight and insert threaded adaptor. Code: B-083</i>						
XT 125X	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
XT 250	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
XT 600	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
XT 660	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <i>or</i> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		BBZ-001 (Fabric guards)
XT 660R <i>2004 on</i>	BHG-046 (Hardware) + JET-003 (Jet guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards) <i>NOTE: To fit BHG-046: Requires two additional M6 x 35mm Flat Head Bolts. Code: R-M6x35FHCSZP (x2)</i>		BHG-046 (Hardware) + VPS-003 (VPS guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-046 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-046 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
XTZ 660 TENERE <i>2008 on</i>	BHG-019 (Hardware) + JET-003 (Jet guards)		BHG-019 (Hardware) + VPS-003 (VPS guards)	BHG-019 (Hardware) + STM-003 (Storm guards)	BHG-019 (Hardware) + BCF-003 (Carbon guards)	
XTZ 1200 SUPER TENERE <i>up to 2013</i>	BHG-040 (Hardware) + JET-003 (Jet guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + JET-003 (Jet guards)		BHG-040 (Hardware) + VPS-003 (VPS guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + VPS-003 (VPS guards)	BHG-040 (Hardware) + STM-003 (Storm guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-BK (Complete kit)	BHG-040 (Hardware) + BCF-003 (Carbon guards) <i>or</i> <i>Weather protection only, fit</i> STM-007-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
XTZ 1200E SUPER TENERE <i>2014 on</i>	BHG-053 (Hardware) + JET-003 (Jet guards)		BHG-053 (Hardware) + VPS-003 (VPS guards)	BHG-053 (Hardware) + STM-003 (Storm guards)	BHG-053 (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
XV 1600				STM-002-00-BK (Complete kit)	STM-002-00-NP (Hardware) + BCF-003 (Carbon guards)	
XVS 650	STM-005-01-NP (Hardware) + JET-003 (Jet guards)		STM-005-01-NP (Hardware) + VPS-003 (VPS guards)	STM-005-01-BK (Complete kit)	STM-005-01-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
XVS 950				STM-002-00-BK (Complete kit)	STM-002-00-NP (Hardware) + BCF-003 (Carbon guards)	
YBR 250				STM-001-00-BK (Complete kit)	STM-001-00-NP (Hardware) + BCF-003 (Carbon guards)	BBZ-001 (Fabric guards)
YZ 80		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
YZ 85 <i>2002 on</i>		EGO-004 (Complete kit)	VPS-007 (MX complete kit)			
YZ 125	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <i>or</i> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		

MODEL	JET	EGO	VPS	STORM	CARBON	BBZ
YZ 250	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		
YZ 250F 22mm (7/8") handlebar	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		
YZ 250F tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		
YZ 450F 22mm (7/8") handlebar	JET-001 (Complete kit)	EGO-001 (Complete kit)	BHG-151 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-151 (Hardware) + STM-003 (Storm guards)		
YZ 450F tapered handlebar	JET-002 (Complete kit)	EGO-005 (Complete kit)	BHG-152 (Hardware) + VPS-003 (VPS guards) <u>or</u> VPS-007 (MX complete kit)	BHG-152 (Hardware) + STM-003 (Storm guards)		